



QUALITY & INNOVATION  
THAT **INSPIRES**

## OUTDOOR MODELS

### SPRING START UP FOR PERLICK OUTDOOR PRODUCT

**IMPORTANT: THESE INSTRUCTIONS ONLY APPLY TO PERLICK OUTDOOR MODELS ONLY.**

Spring start up can occur when the daily low temperature is at or above the temperatures stated below:

Freezer models: **32°F (0°C)**

Refrigerator models: **38°F (3.3°C)**

Beverage Center models: **42°F (5.6°F)**

Wine Reserve models: **45°F (7.2°F)**

Beer Dispenser models: **38°F (3.3°C)**

Dual-Zone models: **Refer to the warmest temperature compartment above**

1. Remove the front grill from the unit.
2. Check the condensing unit to ensure it is clear of loose debris, and clean if necessary with a vacuum cleaner.
3. Reattach the front grill to the unit.
4. Clean the interior and exterior using stainless steel cleaner and polish.
5. Plug the unit into the electrical receptacle or turn on the circuit breaker.
6. Turn on the master switch located behind the grill for Signature Series models. Press the "OFF" button one time to turn the unit on. The controller will show the actual temperature inside the cabinet.
7. The cooling process will begin to bring the unit to the set temperature. It's recommended that you run the unit for 24 hours to stabilize the operating temperature before using.